



Assembly Guide

TIPS

To detach the parts from the board, press the anchor point with your thumb.
 Always push with your thumb on the engraved side of the board, so the piece falls under the board.
 You can easily locate the anchors points by looking at the back of the board.
 Use PVA glue diluted with a little water. (3 parts adhesive, 1 part of water).
 Use a small file to remove the anchor points' residues. You can also use a modeler's knife (handle it carefully to prevent injury).
 Use a small brush to spread the diluted glue.



Urban warzone A - Guide



Join [A1] and [A5]



Insert [A2] into [A5]



Insert [A3] into [A5]



Insert [A4] into [A5]



Close the corner with [A6]



[A7], [A8] and [A9] form the next assemblage



Join [A12] and [A11]



Insert [A13] into [A11]



Complete the assemblage with [A10]



Gather all the [Z] parts.
 You should have twenty one



Glue a [Z] part into each
 window of each ruin



The parts on the left represent planks or beams and
 the ones on the right represent pieces of broken concrete.

We recommend that you glue the concrete parts now,
 but keep the beams to paint them separately and add them
 to the models at the end, especially, if you choose to use a
 textured spray on the models.

